



**Seat Height Adjustment** — Enables the seat to adjust to the preferred height.

To raise the seat, lift your weight off the seat and pull up on the lever; release lever when seat reaches desired height.

To lower the seat, lift up on the lever while you are seated; release lever when seat reaches desired height.

**Seat Angle Adjustment** — Allows user to independently position and lock the seat angle relative to the floor.

Pull the lever up to unlock and free float.

Adjust to preferred angle and push the lever down to lock into position.

**Back Angle Adjustment** — Adjusts the angle of the back relative to the seat.

Pull the lever up to unlock and free float.

Adjust to preferred angle and push the lever down to lock into position.

**Back Height Adjustment** — Provides custom lumbar support.

From a seated or standing position, lift up on the back to adjust the back height to one of five preset positions.

Lift the back to its maximum height in order to release the internal back height mechanism and return the back to the lowest position.

**Arm Height Adjustment** — Enables the user to adjust the arms based on body size, task, and personal preference.

Lift up on lever, and adjust arm height to desired position.

Release lever to lock arm into place.

**Arm Width Adjustment** — Enables the user to adjust the arms based on body size, task, and personal preference.

Turn knob counterclockwise to loosen.

Adjust arm in or out to desired width.

Turn knob clockwise to tighten.