

# Allsteel®

Designed to work. Built to last.

## SEATING

### Trooper Task Stool



**Seat Height Adjustment** — Enables the seat to adjust to the preferred height.

To raise the seat, lift your weight off the seat and pull up on the lever; release lever when seat reaches desired height.

To lower the seat, lift up on the lever while you are seated; release lever when seat reaches desired height.

**Back Height Adjustment** — Provides custom lumbar support.

From a seated or standing position, lift up on the back to adjust the back height to one of five preset positions.

Lift the back to its maximum height in order to release the internal back height mechanism and return the back to the lowest position.

**Arm Height Adjustment** — Enables arms to adjust to your body size and personal preference.

Lift up on lever, and adjust arm height to desired position.

Release lever to lock arm into place.

**Arm Width Adjustment** — Enables arms to adjust to your body size and personal preference.

Turn knob counterclockwise to loosen.

Adjust arm in or out to desired width.

Turn knob clockwise to tighten.

**Footring Height Adjustment** — Ensures comfortable position for feet and legs, regardless of chair position or user height.

Turn knob counterclockwise to loosen.

Move footring to desired height, making sure that the thread on the adjustment knob is seated into one of eight retaining slots.

Turn knob clockwise to tighten.